



FITTING INSTRUCTIONS

BMW R1100GS & R1150GS – Rear Rack Extension



Contents

- 1 x Rear Rack Extension
- 2 x M6 fixings

1. Remove rear grab rail by carefully undoing the two cap head bolts securing the rail to the rear bodywork.
2. Place the rear rack extension on the existing rear rack and slot the rear grab rail into the locating holes
3. Attach using existing cap head bolts and secure to rear bodywork
4. Attach to rear of original rack using supplied M6 fixings.

