



FITTING INSTRUCTIONS

BMW R1150GS and R1150GS Adventure – Oil Cooler Guard



Contents

1 x Oil Cooler Guard

1. Unscrew the two front indicator lenses, remove the bulb assembly and loosen the cables from the housing.
2. The cables must be pulled through the indicator stalk inwards, so that you can remove the indicators.
3. Undo the six retaining bolts of the front beak, so that it can be removed.
4. Loosen the two outside screws, which secure the headlight mount.
5. Easing the headlight mount upwards, you can slide the oil cooler guard in front of the oil cooler.
6. To re-assemble please attach in reverse order of above instructions

