



FITTING INSTRUCTIONS

BMW R1200GS & BMW R1200GSA – Throttle Potentiometer Guard



Contents

- 1 x Throttle potentiometer cover
- 3 x M4 washers plain
- 3 x M4 spring washer
- 3 x M4 screws
- 2 x nylon spacers

1. First carefully remove original screws from potentiometer.
2. Add spring washer and plain washer to screw and place through the M4 size holes on the potentiometer guard.
3. Insert nylon spacer over screw to the inside of the guard.
4. Carefully attach guard over the potentiometer and tighten screw.

