



FITTING INSTRUCTIONS

BMW R1200GS and R1200GS Adventure – Fat Foot

These Instructions Apply To All Model Years



Contents

1 x Fat Foot

1. This item is supplied pre-assembled.
2. The upper plate needs to be removed and placed over the side-stand.
3. The remaining plates attach to the upper plate using the fixings supplied and are secured by the nyloc nuts.

