



FITTING INSTRUCTIONS

BMW R1200GS & R1200GS Adventure – Rear Brake Reservoir Guard



Contents

- 1 x Rear Brake Reservoir Guard
- 1 x M6 washer

1. Remove Seat.
2. Remove the rear brake reservoir retaining bolt
3. Attach the guard over the brake reservoir and re-attach to mounting using the washer and original bolt.



NOTE: If lower seat position is in use, the position of this Rear Brake Reservoir Guard may need to be adjusted.

