



FITTING INSTRUCTIONS

Honda XRV750 – Chain Guard

These instructions apply to RD04, RD07 & RD07A models



Contents

1 x Chain Guard

2 x M6 fixings

1. Attach rear support bracket to Chain Guard using supplied screws, washers and nyloc nuts
2. Remove original black plastic chain guard remembering the locating tab at the tear of the guard.
3. Attach Rugged Roads Chain Guard using supplied M6 bolts into original mounting holes.

